

8.-TABELLA RIASSUNTIVA DELLA MANUTENZIONE PREVENTIVA

OPERAZIONI DA ESEGUIRE	COMPONENTI DELLA TORRE	SPURGO	VASCA	VALVOLA GALLEGGIANTE	DISTRIBUZIONE DELL'ACQUA	SEPARATORE DI GOCCE	MOTORE	VENTILATORE	PANNELLATURA	FUNZIONAMENTO CON CLIMI FREDDI
ISPEZIONE PER LE INCROSTAZIONI					M	M		N		
ISPEZIONE DELLE CONDIZIONI GENERALI			N	M	M	M		N	S	N
PULIZIA E DISINFEZIONE			M		M/N	S/N	S	M	S	
RIVERNICIATURA			N				N		N	
LIVELLO DELL'ACQUA NELLA VASCA			M							
ISPEZIONE PER SURRISCALDAMENTO, RUMORE E VIBRAZIONI							D			
ISPEZIONE PER LE PERDITE			N		M				N	
SERRAGGIO DEI BULLONI E DELL'ANCORAGGIO								N		
EQUILIBRATURA ED ALLINEAMENTO										
LUBRIFICAZIONE							N			
VERIFICA DEL FLUSSO DI SPURGO E DEL CICLO DI CONCENTRAZIONE		D								

D = GIORNALIERO
S = SEMESTRALE

M = MENSILE
N = SE NECESSARIO

8.- PREVENTIVE MAINTENANCE SUMMARY CHART

	COOLING TOWER COMPONENTS										
	BLOWDOWN	GRID	BASIN	WATER MAKE-UP	ELECTRIC PUMP	WATER DISTRIBUTION	DRIFT ELIMINATOR	MOTOR	FAN	CASING	COLD WEATHER OPERATION
OPERATIONS TO BE CARRIED OUT											
INSPECTION FOR FOULING		M					M	M			
INSPECTION OF THE GENERAL CONDITION			N	M		M/N	M	M			
CLEANING AND DISINFECTION		M	M		M/N	M/N	S/N	S	M	S	N
REPAINTING			N		N			N		N	
BASIN WATER LEVEL			M								
INSPECTION FOR OVERHEATING, NOISE AND VIBRATION					N			D			
INSPECTION FOR LEAKS			N			M				N	
TIGHTENING OF BOLTS AND ANCHORING					N				N		
BALANCING AND ALIGNMENT											
LUBRICATION					N			N			
BLOWDOWN FLOW AND CONCENTRATION CYCLE CHECKING	D										

D = DAILY
M = MONTHLY
S = SIX-MONTHLY
N = WHEN NEEDED